

Tools Required: Tape measure, marking tool, aviation tin snips

- 1) Place the Tile Replacement Flashing matching the roof's tile profile over the installed tile hook to ensure proper fitment, then mark the right side of the flashing about 2" up from the bottom edge.



- 2) Using a pair of tin snips, trim the flashing to create a small tab.



- 3) Fold the tab flat by hand and bend the tab under the adjacent tile to secure the flashing.



- 4) Form Tile Replacement Flashings by hand as needed to improve the way the flashing fits against the adjacent tiles and to ensure the tiles can sit flush once lowered into position.
 - Pro Tip: If working in areas prone to high wind, IronRidge recommends securing the flashings further by driving a roofing nail through the small hole in the top of the flashing.

