

**Tools Required:** Utility knife, QuickGrip® 50'x4" Roll

**Installation Temperature:** Min Ambient Temp = 5°F (-15°C) / Max Ambient Temp = 118°F (48°C)

- 1) Begin by unrolling a small section of QuickGrip® sealant tape (about 12").
  - Make sure to place a spare piece of wood or something under the tape to provide a good cutting surface that will prevent damage to the surface below it.



- 2) Place roof attachment base over the sealant tape, centering the base within the 4" width of the sealant tape.
  - It's best not to remove the release liner until after the QuickGrip® has been cut to size.
  - QuickGrip® Sealant Tape is double-sided and can be cut and applied using whatever method is preferred.



- 3) Using the base of the roof attachment as a guide, carefully cut around the circumference of the attachment base using a sharp blade like a utility knife.
  - For larger projects, it may be best to utilize something like a heavy-duty tabletop guillotine paper cutter to expedite the cutting process.



- 4) The trimmed QuickGrip® flashing can be applied to the bottom of the mount at any time by simply peeling back the translucent release liner and applying the QuickGrip® to the bottom of the attachment.
  - Pro Tip: Use the tip of a utility knife blade to start release liner removal.
  - For QBase, the cap screw for the post MUST be inserted into the bottom hex slot prior to applying QuickGrip®.



- 5) Remove the second release liner exposing the QuickGrip® applied to bottom of the attachment.
- Because QuickGrip® has a sticky surface it's usually best to wait until just before you install the attachment to remove the release liner.



- 6) Clean roof area of all debris where attachment is to be placed. With the release liner removed, place roof attachment in the desired location and install per the manufacturer's instructions.
- Double-check attachment location before placing roof attachment as the QuickGrip® may be difficult to remove after being adhered to the roof.
  - Installation Manuals for all roof attachments can be found on our website at [www.IronRidge.com](http://www.IronRidge.com).



## Roof Attachments Approved for Use With QuickGrip® (QM-QGRP4-01-M1)

Knockout Tile Base(see Ironridge Parts Catalog for various part numbers)

QBase(see Ironridge Parts Catalog for various part numbers)

### UL 2703A Ratings:

- Conforms to UL SUBJECT 2703A
- Approved for Steep Slope Roofs (2:12 and up)
- Knockout Tile Base plus QuickGrip® approved for Tile Roofs
- QBase plus QuickGrip® approved for Tile Roofs
- Installer must verify roof slope prior to installation